




Indoor Mini Dome Network Camera Connection Diagram




Connect the product to the switch hub and PC.

Prepare the product, your PC and switch hub ready for connection. Make sure that your PC has a LAN port available for connection to the network cable of the product.


Connect to the power source (as shown in the figure).

Please connect with your power adaptor directly.



(as shown in the figure).

Prepare the product, your PC and switch hub ready for connection. Make sure that your PC has a LAN port available for connection to the network cable of the product.



5 Connect to speaker

Connect the speaker to the "LINE OUT" socket.



Turn on the power of the PC and hub.

Connect to the switch hub (as shown in the figure). Use a network cable and plug it in the LAN port of the product. Plug the other end of the cable in the LAN port of the hub.




Connect to microphone in. Connect the microphone with 3.5mm phone jack into the "MIC IN".



6 Connect to Alarm/Reset

Connect to an extension I/O terminal block which is used to connect external infrared detectors, beepers and smoke detectors.



For more information, please refer to the attached CD